



3. Operating elements



Electrical connection



Sensor connection

Plug DIN 43650 3-pin + PE Analog input No. 1 and 2	Current input 4...20 mA (2-wire)	Current / voltage input 0...10 V, 0...20 mA (3-wire)
Pin 1	+Ub	+Ub
Pin 2	---	-Ub
Pin 3	Signal	Signal
Earth	PE	PE

(In combination with 2-wire circuit pin 2 is not required)

Barksdale

CONTROL PRODUCTS

Barksdale GmbH

Dorn-Assenheimer Strasse 27
D-61203 Reichelsheim / Germany

Tel.: +49 - 60 35 - 9 49-0


Fax: +49 - 60 35 - 9 49-111 and 9 49-113

e-mail: info@barksdale.de

www.barksdale.de

Operating Instructions 4-fold Trip Amplifier UAD 3 - V3

Dimensions (in mm)



1. Product description

Intended applications

- The trip amplifier is only to be connected to input signals according to the values on the type label at the bottom side of the device.

2. Starting operations

- The pressure switch should be installed and operated only by authorized personnel.
- Cover and bottom of the device form a function unit. Exchanging the parts can cause measuring errors or malfunctioning. For wall mounting remove the four front cover screws and the front cover. Then fasten the device with four screws to the wall and finally remount the front cover. To damp strong vibrations shock mounts must be used.
- Connect the sensor to the (3-pin + PE) cube plug at the bottom side of the UAD 3 - V3.
- The electrical connection (supply, analog output switching contacts) must be carried out according to the connection tables depicted on the top of the device by removing the cover cap and insert the cable through the cable gland PG 13,5. If required, additional cable glands can be installed in the cover cap by breaking out the perforated cavities.
- The electrical connection must be carried out in accordance with the VDE 0100 regulations. In order to ensure trouble-free operation it is essential to connect the protective lead.
- If inductive loads (magnets, contactors, etc.) are connected to the switch relays, suitable protective devices (varistors etc.) must be provided.

List of functions UAD 3 - V3

Main Menu	Sub Menu	Value	Description
Measur. mode	Display of the actually measured value and the measuring unit
MENU		UNLK LOCK	Display keylock No keylock, all parameters can be adjusted Keylock active, all parameters visible but can not be changed
SP1...SP4	MODE ON OFF LEV DEL SPSC	STND WIND ERRO HLFS LLFS 0,0s..9,9 s DSP1 DSP2	Switch point menu SP1..SP4 Standard evaluation (rising/falling) Window technology Error output Switch-on value for SP1...SP4; if the ON-value is smaller than the OFF-value, the switch evaluation is falling Switch-off value SP1...SP4 Inversion of the switching output High-level-fail-safe (Normally Open function) Low-level-fail-safe ((Normally Closed function) Switch-on / switch-off delay for SP1...SP4 in seconds Switch point reacts on display values of display 1 Switch point reacts on display values of display 2
ANO1...ANO2	ANOP AOZS AOFS	ON OFF	Analog output menu Analog output in operation Analog output switched off Scale the analog output - start value (e.g. 0 bar = 4 mA) Scale the analog output - end value (e.g. 400 bar = 20 mA)
DISP1...DISP2	MODE UTXT DAMP OFFS CUT BGZS BGFS	STND DIFF ABCD 0,0s..9,9 s	Display menu Display channel 1 resp. channel 2 Display difference between channel 1 and ch. 2 (ch. 1 – ch. 2) Enter the measuring unit as text Damping of the displayed measuring value in seconds Measuring value -Offset, means shifting the display range Cut-Off, means signal-suppression within the cut-off range Scale the bargraph - start value Scale the bargraph - end value
PEAK	MIN CLRM MAX CLRXX NO YES NO YES	Peakholding menu Display the peak value „Min“ no deletion delete „Min“-value memory Display the peak value „Max“ no deletion delete „Max“-value memory Attention: At first the peak value menu for channel 1 in display 1 is indicated, then for channel 2 in display 2.
CAL1...CAL2	DECP ZSCL FSCL CODE	0000..0,000	Calibration menu Determination of the decimal-point for the measuring value Scale the measuring-value indication - start value Scale the measuring-value indication - end value Calibration of the manufacturer

4. Operation

After the unit is switched on, the unit starts an automatic self-test.
The device is menu operated and configured by the three keys on the front.
With the „M“ key (= mode) you change between the operation / indicating level to the dialog values and the adjusted / actual values. With the keys („↑“ = up) and („↓“ = down) you change between the dialog values in the menu or change the values / functions in the menus.

A change of any configuration starts always with the M-Mode and indicated by the flashing cursor. After a change has been made with the up- resp. down-key the M-mode key must be pressed to confirm each configuration; to set numbers, each digit has to be confirmed with the M-Mode before adjusting the next one. By confirming the last digit the new configuration will be stored in the memory.
Pushing the down key at the end of the sub-menu the software will switch automatically to the main-menu.

If the dialog is not continued within two minutes the device automatically returns to the measuring mode.

5. Key lock

Activating the („↑“ = up) and („↓“ = down) keys together for more than 5 seconds will block any changings in all menus; shown by „LOCK“ in the display.
In this mode, all configuration values can be checked only, but not changed.

Repeating this action will unlock the configuration menu and shown by „UNLK“ in the display.

6. Error handling

The internal self-check software will monitor the proper functioning of the unit. When any of the following failures will occur, the flashing display will indicate the following text:

Display	Error	Cause
max	Positive excess of the measuring range Channel 1 (indicated in display 1) positive excess of the measuring range Channel 2 (indicated in display 2)	The measured value exceeds the max. of the range
min	Negative excess of the measuring range Channel 1 (indicated in display 1) negative excess of the measuring range Channel 2 (indicated in display 2)	The measured value is lower than the min. of the range
anao	Failure of the analog output 1 (indicated in display 1) Failure of the analog output 2 (indicated in display 2)	Output loop is not closed or short circuited
data	Stored data failure (EEProm) (internal)	Memory failure
prog	Processor failure (internal)	Microcontroller failure
cal	Calibration error channel 1 (internal) (indicated in display 1) Calibration error channel 2 (internal) (indicated in display 2)	Calibration values are wrong

Measuring mode

Menu Structure UAD 3 - V3

